



HOLE H002 P&A SCHEMATIC

NOTES:

1. DEPTHS SHOWN ARE FROM RIG FLOOR.
2. DYE MARKER TO BE PUMPED BEFORE CEMENTING TO CONFIRM HOLE VOLUME.
3. LIQUID SPACERS NOT SHOWN.
4. MECHANICAL SPACERS (SPONGE BALLS) TO BE USED IN CONJUNCTION WITH LIQUID SPACERS.